











Keyboard shortcuts





Switching between modes

Icon	Key	Action
	N	Navigation (Multi Nav) mode
	B	Blanking mode
	C (or X)	Cut Section mode
	P	Navigation (Pan Only) mode
	O	Navigation (Rotate Only) mode
	Shift	Hold to temporarily switch back to Navigation mode

Navigation




Icon	Key	Action
	A	Auto fit the model to the window
	+	Zoom in
	-	Zoom out

Blanking

Icon	Key	Action
	Ctrl + Z	Undo the previous blanking action
	Ctrl + Y	Redo the previous blanking action
	R	Reverse the model blanking state i.e. blank visible and unblank hidden
	U	Unblank all parts in the model



Animation

Icon	Key	Action
	Spacebar	Play/pause the animation
	Left Arrow	Increment backwards one frame
	Right Arrow	Increment forwards one frame

Preset views

Icon	Key	Action	Icon	Key	Action
+XY	1	Top view (Plan)	-XY	5	Underside view
+YZ	2	Elevation	-YZ	6	Elevation
+ZX	3	Elevation	-ZX	7	Elevation
+ISO	4	Isometric view	-ISO	8	Isometric view